

M-ROCK M-Brick

INSTALLATION OF M-BRICK (MANUFACTURED BRICK SERIES)



Stack - Fasten - Grout. It couldn't be easier

READ:

- Read the instructions and be familiar with local building codes.
- Ensure that you have all the tools and supplies you will need.
- We are here to help, just call customer service 866-896-7625.

WHAT YOU'LL NEED:

- 30# felt moisture barrier
- Level and chalk line
- Electric Drill
- M-Grout and grout bag

FASTENER CHOICES:

- Drywall screws/anchors
- Exterior grade screws
- Staples
- Construction Adhesive

PREPPING THE SURFACE

Exterior Untreated Wood Installation: For exterior untreated wood installation a moisture barrier of 30# felt doubled or a synthetic barrier is required.

Exterior Treated Wood Installation: Moisture barrier of 2 layers of 30# felt is recommended when using treated plywood.

Interior Wood Installation: No moisture barrier is required.

Interior Dry Wall: M-BRICK can be installed over Dry Wall, 1) Hit one stud per stone, or 2) Use some type of dry wall anchor.

Block Installation: M-BRICK can be installed over block using masonry screws to apply stone to block. Moisture barrier of 2 layers of 30# felt is recommended. We also recommend that the block be sealed before M-BRICK installation.



STEP 1: STARTING OFF RIGHT

For exterior application, apply 2 layers of 30# felt, wrapping corners. Starting at the base of your project using a level strike a horizontal chalk line. Install your first row of brick using 2 screws. Corner pieces help make your project look professional and refined. If you have a project with corners, install the corner piece first and work your way out from there.



STEP 2: SECOND ROW AND UP

Next, using the arrow on the top rail, line your brick up to the left or right to maintain vertical alignment. The patented rail system will give you the perfect grout line every time all the way around.



TIP: When bricking around windows brick rope can be used to wisk moisture away from the window.

STEP 3: FINISHING IT OFF

Depending on how you grout the bricks afterwards will significantly change the overall look.

- Using M-Rock's M-Grout and a grout bag, squeeze mortar into the grout joints making certain to completely fill all voids.
- Strike joints using a stick or grouting tool after grout is thumb print dry.
- Whisk away any loose mortar.
- M-Brick beautifully finishes to any trim.

