

M-ROCK P-Series / MSI

MSI POST/COLUMN SURROUND INSTALLATION GUIDE

Read the instructions and become familiar with the stone.

- Watch the Installation video at www.m-rockstone.com
- Ensure that you have all the parts, fasteners and tools that you will need.
- We are here to help. Just call customer service 866-896-7625.

COLUMN STONE

Each column stone is custom designed for installation right out of the box.



Starter Pack Contents:

[5] 40 in. Starter Strips

Additional Supplies needed:

- Drill and appropriate driver
- Screws (1¼ min.) Galvanized or dipped in exterior coating
- Recommended 30# Felt moisture barrier
- Polyurethane Construction Adhesive
- Masonry, circular or table saw with diamond blade



STEP 1:

Wrap your column in 2 layers of 30# felt. Install a starter strip on each side of the post. Each starter strip should be installed with two screws drilled through the channel.

STEP 2:

Channel



Lock shape

There are 4 different shaped stones.

1 onto the starter strip followed in sequence by shapes 2, 3, and 4. DO NOT screw any of the sections to the post until all four are in place. Each section of the first level will require one screw. Do not over tighten the screws; only tighten until snug or until no visible gap in corners.



STEP 3:

Rotate 1/4 turn and repeat Step 2 by stacking the next row directly on top of the first row and continue with each additional row. As you are working up the post, other necessary adjustments may need to be made.

STEP 4:

Cutting may be necessary to finish the top row. If you have to make any cuts, do not cut the bottom section of the rail on the stone, so that it can still be locked into place. Make your cut and set the stone into place to assure the fit. Once you are confident that your fit is correct, use a quality Construction Adhesive. Apply the desired amount to the top and back section and along each vertical butt joint, ensuring that the stone is locked into place.

COLUMN CAP

Designed for the 6"x 6" post surround system. To top/cap your post. It is designed with a 2" over hang to cover the last row of post surround and the "pyramid" design is for both function and look. You simply attach your Pyramid Post Cap with a quality Construction Adhesive.



COLUMN TRIM

These trims allow your post to continue up and it is designed specifically for our MSI 6"x 6" Post Surrounds. Designed to allow your post to continue up, while trimming the top of the post surround with a nice finished look. The trim ring comes in two pieces and will need to be installed with a quality Construction Adhesive, leaving a 1/8" or 1/4" gap between the top of the post and your trim. Apply the Construction Adhesive along the bottom groove and where the two pieces will meet. Caulking around the Post Trim Ring may be needed.

